for VM800L RGB III
Wireless Mouse
User Manual

Thank you for purchasing the VXE product.
Please read this manual carefully before using the product to ensure proper use.
Please keep this manual for future reference.

Precautions

Read the following information carefully before using the product to avoid damage or misuse.
Please follow these precautions when using the device to ensure its safety.

Meaning of symbols

DANGER
Failure to follow the instructions may result in serious injury and may even pose a risk to life, serious injury, or property damage.

WARNING
Failure to follow the instructions may result in the possibility of serious personal injury or death and, in rare cases, serious injury.

CAUTION
Failure to follow the instructions may result in personal injury and/or damage to the device or other property.

Symbols:
Prohibited actions
Actions required
Reminder for detail attention
Symbols and Meanings in Illustrations

DANGER

- Never use the charging cable included with the product on equipment not explicitly recommended.
Using an incompatible charging cable may cause overheating, fire, electric shock, or damage to the device. Only use the charging cable provided with the product or a cable explicitly recommended for use with this device.
- Never attempt to disassemble, modify or repair the product.
Doing so may cause fire, electric shock, or product damage.
Contact customer service for repairs.
- Keep out of reach of children.
Small parts may cause choking hazards. Children should be supervised when using the product.
- Use only as you would battery-operated devices.
Follow local laws and regulations when disposing of the device.
Do not dispose of batteries in fire or with hazardous or flammable materials.
- Avoid any water spillage into the product.
Do not use the product near water, such as near a bathtub, sink, shower, swimming pool, or in a damp basement.
- Do not place the product in environments with temperatures above 40°C/104°F.
Do not leave the product in a hot car during hot weather.
- Do not use damaged charging cables.
Do not use the product if the charging cable has been damaged (for example, bent, pierced, cut, or exposed wires).
- Keep the product away from heat sources.
Do not place the product near heating devices, such as radiators, heat registers, stoves, or other devices that produce heat.

WARNING

- If you have metal in your body, such as a pacemaker, please consult a doctor before using the device.
Avoid placing the product in a way that it may interfere with it.
- If the product is not going to be used for an extended period of time (for example, when traveling), remove the batteries to prevent damage from battery leakage.
Store the product in a cool, dry place.
- Keep the product away from strong magnetic fields.
Avoid placing the product near devices that generate strong magnetic fields, such as speakers or transformers.
- Store the product in a cool, dry place.
Avoid exposing the product to direct sunlight or heat sources.
- Do not use the product if it is damaged.
Inspect the product for any signs of damage before use.
- Avoid using the product in a manner that could cause repetitive strain injury.
Take breaks and use ergonomic practices when using the product for extended periods.

CAUTION

- Do not place the product in any of the following environments:
Areas with poor ventilation (e.g., inside a closed bag)
Areas with excessive dust or dirt
Areas with excessive vibration
Areas with a corrosive gas (such as salt air or sulfur)
- Prevent pets and very young children from chewing on the product.
Keep the product out of reach of pets and very young children.

Keeping this product

- Avoid exposing the product to extreme temperatures.
Keep the product away from heat sources, such as radiators, heat registers, stoves, or other devices that produce heat.
- Avoid exposing the product to moisture.
Do not use the product in the rain or near water.
Do not place the product in areas with high humidity.

IMPORTANT

- Do not use any tools to open the product.
Doing so will void the warranty.
- Do not use liquids, aerosols, or solvents to clean the product.
Use only a dry, soft cloth to clean the product.
- Do not attempt to fix a case of inaccurate aim on.
- Keep using the mouse in a clean environment.
Avoid using the mouse in dusty or dirty environments.
- Keep the mouse away from strong magnetic fields.
Avoid placing the mouse near devices that generate strong magnetic fields, such as speakers or transformers.
- Do not use the mouse if it is damaged.
Inspect the mouse for any signs of damage before use.
- Avoid using the mouse in a manner that could cause repetitive strain injury.
Take breaks and use ergonomic practices when using the mouse for extended periods.
- Keep the mouse out of the reach of children and pets.
Small parts may pose a choking hazard.
- Dispose of the mouse and batteries responsibly.
Follow local laws and regulations when disposing of the mouse and batteries.
Do not dispose of batteries in fire or with hazardous or flammable materials.

Cautions for Wireless Equipment

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WARNING

- Exposure to radio frequency energy is a concern. You can minimize risk by using the device only as described in this manual or by consulting a physician to discuss limiting your exposure to RF energy or the use of this or any device in your specific environment. You can also minimize risk by following the guidelines for safe and effective operation in this manual.
- Use only the supplied and approved antenna. Use of unauthorized antennas, modifications, or attachments could damage the device and may violate regulations governing radio devices.
- Do not hold, touch, or position the antenna unnecessarily when the device is in use. Doing so may impact call performance and may cause the device to operate at a higher power level than needed.
- Avoid using the device when any part of the antenna is damaged. A damaged antenna may cause a minor burn to the skin.

How to use

Items included in this package

The following components are included in the package. Check that all items are present and undamaged before use. If any items are missing or damaged, contact customer service immediately. Keep the packaging in case you need to transport or store the device in the future and avoid damage.
Mouse x1
Receiver x1
Instruction & Warranty x1
Type-C to Type-C cable x1
USB-type-A to C adapter x1
Type-C to Type-A cable x1
Silicone grip tape x1
Grip tape x1
Foldable top shell x 1

Appearance and buttons

Mouse

1. Left button
2. Right button
3. Wheel
4. Scroll wheel
5. Rear button
6. Forward button
7. Type-C port
8. Sensor

Receiver unit

1. USB connector
2. Type-C to Type-C cable port

Connecting and setting up the mouse

Wired or Wireless mode

1. Charging the battery
Connect the **USB Type-C** connector of the charging cable supplied in the VXE Team (Left of the picture).

(Connect the **USB-A** connector on the included charging cable to the USB-A port on your PC.



Connect the included Type-C cable to the mouse.
Connect the other end of the Type-C cable to the receiver. The receiver will automatically enter pairing mode.
Wait for a few seconds until the pairing is complete.

(Once on the green or red PC, it's time to start wired, directly, wired mode to.
You can keep the mouse connected to your PC while you play. This is useful for extended play sessions.

Connect the included Type-C cable to the mouse.
Connect the other end of the Type-C cable to the receiver.
The mouse will automatically switch to wired mode.
You can keep the mouse connected to your PC while you play. This is useful for extended play sessions.

2. Turn the power ON
Slide the power switch on the underside of the product to the ON position.

The indicator LED will light up red for 3 seconds. The RGB LED will display light cycle 3 seconds in different colors, indicating it is turned ON and in use.
Then it will blink red once for connecting charging mode.
Wireless mode:
Press the connect button on the bottom for 3 seconds or more to enter pairing mode.
The LED will blink red and green alternately.
Once connected, the LED will turn off.
Wired mode:
Connect the mouse to your PC using the included Type-C cable.
The mouse will automatically enter wired mode.

3. Charging the PC
Other type-given PC
Connect the charging cable to your PC and computer.

(Connect the included adapter and connect cable to the receiver (wireless adapter and insert them into the USB-A port on your PC.

You can turn the RGB LED.
You can switch the mouse to wireless mode.

Connect wireless mode by pressing the DPI key.
Press the wireless button on the bottom of the mouse for 3 seconds or more to enter pairing mode.
The LED will blink red and green alternately.
Once connected, the LED will turn off.
Wired mode:
Connect the mouse to your PC using the included Type-C cable.
The mouse will automatically switch to wired mode.

(If the error will be automatically installed, and you will then be able to use the mouse.
You can even use the mouse.

Wired mode only

1. Connect the to PC
Connect the USB Type-C connector on the charging cable supplied in the VXE Team (Left of the picture).

(Other type-given PC
Keep the mouse to PC for wired to use and connect.

(Connect the included adapter and connect cable to the receiver (wireless adapter and insert them into the USB-A port on your PC.

Connect wireless mode by pressing the DPI key.
Press the wireless button on the bottom of the mouse for 3 seconds or more to enter pairing mode.
The LED will blink red and green alternately.
Once connected, the LED will turn off.
Wired mode:
Connect the mouse to your PC using the included Type-C cable.
The mouse will automatically switch to wired mode.

(If the error will be automatically installed, and you will then be able to use the mouse.
You can even use the mouse.

Note:
Wireless mode is not available in this mode.
Please refer to Page 3 (Wired mode) for more information.

Wiring the mouse (cable)

The mouse is pre-installed with the wire sleeve at the bottom of the mouse. You need to first detach wire and connect to the mouse.
The type-C the mouse can be opposite to the wire sleeve to the mouse top.
Please refer to the picture below for more information.

If your left-handed mouse, the cable should be in position on the left side of the mouse so it can follow from with the wired to reverse wired setup.
Carefully remove the wire sleeve from the mouse.

Replacement mouse feet are available for this mouse.
Please refer to Page 4 (Mouse feet) for more information.

Wiring the mouse (grip tape)

The mouse is pre-installed with the grip tape to ensure a secure grip.
Please refer to the picture below for more information.

1. Before applying the grip tape, ensure your hands are clean and dry to prevent any dirt or moisture from affecting the adhesion.
2. Align the grip tape to the front end of the mouse and position it so that it sits flush with the edge.

3. Apply pressure to the front portion of the mouse and press it to the center of the body.

4. Apply a little more pressure to the sides.

5. Affix the rear edge to the mouse, then apply some pressure to the center of the main buttons.

6. Affix side of the grip to the mouse.

7. Apply the remaining part of the side surface of the mouse.

8. Press the opposite side while smoothing the material to ensure the mat has an even.

9. Attach the grip pieces for the left button and the right button to match the position of each button.

10. Affix the grip piece to the top left.

11. Affix the grip piece to the "wave" and "forward" buttons.

12. You can also attach a grip piece to the bottom of the mouse for extra grip.

13. You can also attach a grip piece to the bottom of the mouse's connector adapter.
If you have used any non-stick tape from your mouse, you can also use it to attach a grip piece to the adapter. You can also remove it if you don't want it.

Please keep all the grip pieces that should stay with the mouse at all times to avoid any of the mouse.
Any excess grips will from the mouse, please do not discard.

Please keep all the grip pieces that should stay with the mouse at all times to avoid any of the mouse.
Any excess grips will from the mouse, please do not discard.

Setting up the FLEXCM GAMING Tool (PC Tool)

FLEXCM GAMING Tool software is available for Windows only. Version 1.0.0 or higher is required to run properly. If you have not installed it, please download and install it first.

Where to find the Tool
Download the FLEXCM GAMING Tool software from the official website.
The software is in the **PC** folder.

Loading the PC Tool
Open the software.
Before installing
Please close all other software to avoid any unnecessary conflicts during the install. Not to connect any other devices to your computer during the installation.
Please follow the on-screen instructions to complete the installation.